

***SIGA OS PASSOS A SEGUIR, PARA
REMOVER O COMANDO “ENTER”
E ADICIONAR “SPACE-BAR”.***

IDTECH[®] *MagSwipe Configuration Utility*

SELECT READER
INTERFACE

HOW TO USE
THIS UTILITY

CHECK CURRENT
READER SETTINGS

CHANGE BASIC
READER SETTINGS

CHANGE ADVANCED
READER SETTINGS


HELP

EXIT



ID TECH readers come with default settings made at the factory. These settings are suitable for most applications and do not need to be changed. However, if you need to change something basic (like beep volume) or something more advanced (like a data editing routine), this utility will help you do it easily and quickly. Start by clicking on one of the tabs on the left side of this page.

IDTECH[®] MagSwipe Configuration Utility



SELECT READER INTERFACE

HOW TO USE THIS UTILITY

CHECK CURRENT READER SETTINGS

CHANGE BASIC READER SETTINGS

CHANGE ADVANCED READER SETTINGS

HELP

EXIT

Change Basic Settings:

General Settings | Pre/Postamble | RS232 Parameters | **Track Settings** | Keyboard Settings

Beep
☐ OFF ☐ LOW ☒ HIGH ☐ Quick HIGH ☐ Quick LOW

MSR Reading
☐ MSR Reading Disabled ☒ MSR Reading Enabled

Terminal Type
☐ IBM PC/AT ☐ IBM PC/AT, External Keyboard
☐ NoteBook ☐ IBM PC/AT, NO External Keyboard

Decoding Method
☐ Raw Data
☒ Decoding In Both Directions
☐ Decoding forward direction only
☐ Decoding reverse direction only

Inter-Character Delay
☐ 2 ms ☐ 20 ms
☐ 5 ms ☐ 50 ms
☐ 10 ms ☐ 100 ms

Default Page Help

Send to MSR Save to File Load from File Default All Close

IDTECH[®] *MagSwipe Configuration Utility*

Change Basic Settings:

General Settings | Pre/Postamble | RS232 Parameters | **Track Settings** | Keyboard Settings

SELECT READER INTERFACE

HOW TO USE THIS UTILITY

CHECK CURRENT READER SETTINGS

CHANGE BASIC READER SETTINGS

CHANGE ADVANCED READER SETTINGS

HELP


EXIT

Track Select

☒ Any Track ☐ Track1 Only ☐ Track2 Only
☐ Track1 And Track2 ☐ Track3 Only ☐ Track1 And Track3
☐ Track2 And Track3 ☐ All Three Tracks ☐ Track1 Or Track2
☐ Track2 Or Track3

☒ Send Start/End Sentinel ☐ Send LRC in Card Data
☐ For Track 2 Only Send Account Number
☐ Send Error Indication

Track Separator: \r Non-Printable Char:
Terminator: \r Non-Printable Char:



IDTECH[®] *MagSwipe Configuration Utility*

SELECT READER INTERFACE

HOW TO USE THIS UTILITY

CHECK CURRENT READER SETTINGS

CHANGE BASIC READER SETTINGS

CHANGE ADVANCED READER SETTINGS

HELP

EXIT

Change Basic Settings:

General SettingsPre/PostambleRS232 ParametersTrack SettingsKeyboard Settings

Track Select

☒ Any Track

☐ Track1 Only

☐ Track2 Only

☐ Track1 And Track2

☐ Track3 Only

☐ Track1 And Track3

☐ Track2 And Track3

☐ All Three Tracks

☐ Track1 Or Track2

☐ Track2 Or Track3

☒ Send Start/End Sentinel


☐ Send LRC in Card Data

☐ For Track 2 Only Send Account Number

☐ Send Error Indication

Track Separator:

Non-Printable Char:



Non-Printable Char:

Default Page

Help

Send to MSR

Save to File

Load from File

Default All

Close

***APÓS APAGAR O COMANDO
“\CR”, PRECIONE UMA VEZ A
BARRA DE ESPAÇO NO (CAMPO
DIGITÁVEL), E EM SEGUIDA
APLIQUE A MODIFICAÇÃO EM
“SEND TO MSR”.***

IDTECH[®] *MagSwipe Configuration Utility*

SELECT READER INTERFACE

HOW TO USE THIS UTILITY

CHECK CURRENT READER SETTINGS

CHANGE BASIC READER SETTINGS

CHANGE ADVANCED READER SETTINGS

HELP

EXIT

Change Basic Settings:

General SettingsPre/PostambleRS232 ParametersTrack SettingsKeyboard Settings

Track Select

☒ Any Track

☐ Track1 Only

☐ Track2 Only

☐ Track1 And Track2

☐ Track3 Only

☐ Track1 And Track3

☐ Track2 And Track3

☐ All Three Tracks

☐ Track1 Or Track2

☐ Track2 Or Track3

☒ Send Start/End Sentinel

☐ Send LRC in Card Data

☐ For Track 2 Only Send Account Number

☐ Send Error Indication

Track Separator:

Non-Printable Char:

Terminator:

Non-Printable Char:

Default Page

Help

Send to MSR

Save to File

Load from File

Default All

Close